




Features

- Works with the Onyyx system
- Sends alarm signals on knocking, vibration or tilting
- Customisable sensitivity
- External connector for 3rd party devices
- Up to 500m line of sight range
- Two way wireless transmission (868Mhz)




Installing the DoorSense Vibe

- Fix the DoorSense Vibe on to the window glass or frame..
- To connect another detector to the external input, simply connect the wires to the AUX IN connector.
- You can use either the


Learning the DoorSense Vibe

Learn the DoorSense Vibe to the Onyx app by scanning the QR code.






DoorSense Vibe




On the device details page, Give the DoorSense Vibe a name and select the area that it must belong to




When using the Doorsense Vibe on a door, toggle on Door Sensor and Specify the Entry/Exit Delay time.



DoorSense Vibe




When using the Doorsense Vibe as a Vibration or Knock Sensor, toggle on Vibration/Knock Sensor and set the vibration/knock sensor level depending on where the device will be placed.



There is a custom option available if you need to fine tune the sensitivity for your specific requirements.

Once done, tap on finish to save the changes and add the DoorSense Vibe to your list of devices.





DoorSense Vibe
